















©2010

Configure your Obi110 to work with VoIP My Way phone service:

1. Visit the Obihai wizard at: <http://www.obihai.com/itspConfiguration/itspConfiguration-generic.html>
2. Enter your device IP (This is usually the public internet facing IP of your device)
3. Give this configuration a name, such as: VoIPMyWay
4. Enter your 3 digit area code.
5. Leave the service provider template as generic for now.
6. SIP Proxy server is : sip.voipwelcome.com
7. SIP proxy port is 5060
8. SIP proxy outbound server is the same as the proxy server so there is no need to set that. The same is true for the outbound proxy port.
9. The user name is your 10 digit account number
10. The password is the SIP password we provided you.

IP Address of OBi Device: *	<input type="text" value="192.168.100.2"/>	
Configuration Name:	<input type="text" value="VoIPMyWay"/>	
Make this the Primary Line to Call Out:	<input checked="" type="checkbox"/>	
7-Digit Dialing for USA & CAN:	<input type="text" value="717"/> Enter Area code e.g. "212"	
Service Provider Template:	<input type="text" value="Generic Service Provider"/>	
SIP Proxy Server: *	<input type="text" value="sip.voipwelcome.com"/>	
SIP Proxy Server Port: *	<input type="text" value="5060"/>	
Outbound Proxy Server:	<input type="text"/>	
Outbound Proxy Server Port:	<input type="text" value="5060"/>	
Username: *	<input type="text" value="717 [REDACTED]"/>	
Password: *	<input type="password" value="••••••••"/>	
URI:	<input type="text"/>	

Fields with * are required.